





Multispectral Imaging Systems


Condor-1000 MS-1-FV

Key Features

- Unique 3 Layer full pixel planes
- Full frame and ROI mode
- 14.1 Megapixels effective
- >6 FPS full frame resolution
- 14 KHz color line scan mode
- Rolling shutter and still shot modes
- Internal black level correction
- Internal image correction pipeline
- User LUT conversion tables
- Test pattern outputs
- Onboard 32Bit processor

Specification:

Sensor	Foveon F13
Resolution	14.1 Megapixels (2652 x 1768 x
3 layers)	
Image area	20.68 x 13.79 mm
Image diagonal	24.86 mm
Pixel clock	40 MHz
Pixel size	7.8 µm square
Aspect ratio	3:2
Data rate	~100 Mbytes/sec
Maximum frame rate	6.9 Fps full frame
	14 KHz Color line scan mode
Data bits	8 to 12 bits per pixel per chan-
	nel selectable
Output	CameraLink (Base, Medium)
	Optical Fibre (3.125Gbps)
	GigE (reduced frame rate)
Dynamic range	> 62dB (measured using green
	photodiode)
Gain range	T.b.d.
Bandpass filter	420-660nm, optional removed
Operating temp	0 50 °C
Power supply	1224 Volts
Power Dissipation	t.b.d.
Mass	t.b.d.
Size (wxhxd)	78 x 83 x 80 mm
Lens mount	F-Mount
Control	Serial port via Interface
Power	Hirose HR10 12Pin





DIRECT IMAGE SENSOR

The Condor-1000 MS1-FV uses the unique 3 layer technology from Foveon. This technology allows the camera to have full optical resolution at all colors without filter array mosaic artifacts. The camera sends out complete images at full resolution for Red, Green and Blue.


The Condor-1000 MS1-FV has 3 different interfaces available. CameraLink is used for demanding real-time applications. The camera can be run at full speed through Base or Medium connections. For long transmission distance applications (>100m), a Fiber Optic interface is available, which can transfer the image at full speed, full resolution and full bit rate. For applications where interface cost is most important and full transfer rates are not required a GigE interface is available.


Because of the unique 3 layer technology and the special registers on the sensor, the Condor-1000 MS1-FV can be operated in a line scan mode with perfect registration in the RGB channels. The RGB data has no spatial offsets in any direction. Unlike other line scan cameras, the Condor-1000 MS1-FV can be instantly switched between line and area operation to facilitate application development and camera alignment.







Iultispectral Imaging Systems







Mechanics are advance information and can be changed before production version.



Distributor information:





Foveon X3® Capture



A Foveon X3 direct image sensor features three

separate layers of pixels embedded in silicon.

Since silicon absorbs different colors of light at different depths, each layer captures a different color.



As a result, only Foveon X3 direct image sensors capture red, green, and blue light at every pixel location.

Mosaic Capture



In conventional systems

mosaic patte

color filters are applied to a

single layer of pixels in a tiled

Ţ





As a result, mosaic sensors capture only 25% of the red and blue light, and just 50% of the green.

......



